

NOTICE DE MONTAGE

SAUTE-VENT & TETE DE FOURCHE ERMAX ADAPTABLE SUR GSX-S 750 2017 → ∞

Temps de montage estimé: 30 mn



Kit de fixation

- 1 tableau de bord ABS
- 3 inserts caoutchouc M5
- 5 vis BHc 5×15 (grosse tête)
- 3 rondelles plastiques Ø5
- 1 inserts caoutchouc M5 collerette large ép. : 5mm
- 1 vis BHc 5×20 (grosse tête)

Montage

- Démontez le cache supérieur du compteur et mettez en place l'insert caoutchouc à collerette large comme sur la photo (le passer par l'intérieur et si besoin, découper des morceaux comme indiqué par les pointillés sur la photo).

- Mettez en place le tableau de bord ABS et le fixez à l'aide de 2 vis BHc 5×15 sur les points d'origine et la vis BHc 5×20 pour le point inférieur.

- Mettez en place les 3 inserts caoutchouc M5 sur le tableau de bord ABS, puis fixez le saute-vent sur ce dernier avec les 3 vis BHc 5×15 restantes et les 3 rondelles plastique Ø5.



« ATTENTION »

* Tout accessoire monté ne sera plus considéré comme neuf et ne sera **ni repris ni échangé**.

* Les accessoires Ermax sont conçus pour des **montes d'origine**. Ils ne seront pas garantis s'ils sont utilisés dans d'autres conditions.

* En raison des tolérances de fabrication des véhicules, indépendantes de notre volonté, certains produits Ermax peuvent nécessiter des ajustements lors de la fixation.

* Attention aux serrages excessifs qui pourraient abîmer ou casser nos accessoires en plastique et les vis en aluminium.

* Les marques de fabricant de motos citées sont indiquées exclusivement comme référence nécessaire à la destination des accessoires Ermax.

* Les bulles abîmées par un **lavage inadéquat** ne sont pas garanties (dissolvant, essence, détergent, produits abrasifs, corrosifs...). Essuyer immédiatement les liquides de frein ou de batterie qui pourraient déborder sur les accessoires.

FITTING INSTRUCTIONS

ERMAX NOSE SCREEN & NOSE FAIRING ADAPTABLE ON GSX-S 750 2017 → ∞

Estimated mounting time: 30 mn



Fitting kit

- 1 ABS dashboard
- 3 rubber inserts M5
- 5 screws BHc 5×15 (big head)
- 3 plastic washers Ø5
- 1 rubber insert M5wide collar, thickness : 5mm
- 1 screw BHc 5×20 (big head)

Fitting instructions

- Remove the upper cover of the meter and place the rubber insert with the wide collar like shown on the photo: pass it through the inside and if necessary cut out pieces as indicated by the dotted lines on the picture.

- Place the ABS dashboard and fit it thanks to 2 screws BHc 5×15 for the original fitting points and the screw 5×20 on the lower fitting point.

- Place the 3 rubber inserts M5 on the ABS dashboard, then fit the nose screen on this last one with the remaining 3 screws 5×15 and 3 plastic washers Ø5.



< CAUTION >

- * Accessories gone up on the motorbike will not be any more considered as new and will be **neither retaken nor exchanged**.
- * Ermax accessories are foreseen for **original equipments**. They will not be guaranteed if they are used in others conditions.
- * Due to vehicles made tolerances, beyond our control, some Ermax products might need adjustings to fit.
- * The mentioned label of motorbikes's manufacturers are indicated exclusively as a reference to Ermax accessories.
- * Care to excessive clampings which may damage or break our plastic accessories and aluminium screws.
- * Screens damaged by an **inadequat washing** are not guaranteed (abrasive, corrosive ... products, solvent, thinner, benzene ...). Wash immediately brake or battery fluid which may flow on accessories.