

INSTRUCTIONS DE MONTAGE JOINT DE FINITION POUR BULLE



Le joint fourni avec la bulle Ermax est une option.

- Faire chauffer le joint pour assouplir la colle à l'intérieur.
- Commencer par une extrémité de la bulle, en laissant 1 cm de plus (en cas de rétractation du joint).



Le joint ne doit couvrir que la partie de la bulle « hors » carénage.

- Positionner le joint en le guidant et en appuyant sur le contour de la bulle jusqu'à l'autre extrémité, en laissant à nouveau 1 cm de jeu. Ne pas trop tirer sur le joint pour qu'il ne se rétracte pas en séchant.
- Laisser refroidir la colle puis couper le joint à la hauteur voulue.

FITTING INSTRUCTIONS SCREEN TRIM



The trim provided
with Ermax screens
is optional.

- Heat the trim to soften the glue inside.
- Start at one end of the screen leaving a 1 cm overhang (in case the trim contracts).



The trim is only intended to cover the part of the screen which is « outside » the fairing.

- Position the trim on the edge of the screen by guiding it and pressing on the curve of the screen all the way to the other end, leaving again a 1cm overhang. Do not stretch the trim in case it contracts as it dries.
- Allow the glue to dry and then cut the trim to the desired length.

« CAUTION »

* Accessories gone up on the motorbike will not be any more considered as new and will be **neither retaken nor exchanged**.